


## EMERGENCY RELEASE


① Unscrew Star Knob

② Lift Off Cover

③ Loosen Red Handle  
Gate can now be manually moved



**Grab the Gate to Make Adjustments**



**Tighten the Red Handle, Replace the Cover and Bolt when Finished**  
When the power is turned on again, the gate will readjust itself automatically.


**Emergency Release**

## EMERGENCY MANUAL RELEASE




*Turn the power OFF!*

**NOTE:** Use the dedicated breaker switch to disconnect power to the operator.




Push the crank tool in hole. Safety releases will separate. Turn the crank to open the gate.




Remove crank tool.

**NOTE:** YOU may use a cordless power drill (6"/sec) for quicker opening in non-emergency situations.



Allen wrench drill bit size is 5/16"

## OPTIONAL MANUAL RELEASE



Pull firmly on the "T" Handle to release the chain.

Contact your local dealer for information about a Fire Box Release.

The chain is held in place by a spring loaded pin.